



Marty's FlexKrete Job Tips

"FlexKrete makes it possible now!"

4/7/2014, VOL IV

REPAIR ALMOST ANYTHING, WITH FLEXKRETE and PUT INTO SERVICE!

Terra Construction of Las Vegas made these columns look brand new. The surface prep usually consists of hand tool or blast cleaning, and to stop the corrosion, the rebar should be double coated with FlexPrime. Sonotubes were used here, starting at bottom and filling with a looser mix of FlexKrete. Carbon fiber wrap can also be installed with FlexKrete resin, to acquire even greater strength than originally existed.

Shown here, Shon Taylor did an excellent job in cold weather, in the repair of ramps and steps. Normally, when repairing on verticals with FlexKrete, it can be hand formed, rather than attaching time-consuming form boards. With the proper mixture sag will not occur, and lines can be kept straight, either with trowels or holding a straight line, and troweling to a board. After the repairs are made the project is made beautiful by broadcasting sand or color quartz onto the surface. On steps, the risers should be broadcast first, by mixing one part fumed silica and one part FlexKrete, then rolling it into place, and broadcasting immediately behind.

